



In OrcaSlicer, go to *File/Import/Import Configurations*




Select all files and folders except 'filament' and click Open.




A message will appear asking you to overwrite the files. Click on 'Overwrite all'.

You can then select the printers from the 'Printer' and 'Process' drop-down lists.



To import the filament profiles, you will unfortunately have to take a small detour:

Go to 'C:\Users\%username%\AppData\Roaming\OrcaSlicer\user\default' and replace the 'filament' folder with the folder you downloaded:



(If you cannot see the 'AppData' folder, simply select Show hidden items under View:)

